



# INSTALLATION DIAGRAM

## Specifications

Rough in dimension: From the floor to the center of bypass approximately 50"

Maximum distance and size for drain line: 50' horizontal, 10" vertical rise, using 1/2" ID drain line

Maximum distance and size for brine line: 15' horizontal (see note) using 1/4" ID poly tubing

**NOTE:** The horizontal distance for the brine tank can be increased to 35' if the brine tank is installed above the unit.

**EXAMPLE:** Softener installed in the basement and brine tank installed on 1st floor. The brine tank **CANNOT** be installed below the bottom of the unit. The drain and brine lines should **NOT** be installed with tubing that can collapse. This will cause the unit to malfunction.

**CAUTION:** Do **NOT** connect drain line tubing from control valve to overflow fitting/tubing on brine tank.

